



FTP-V Solar, FTP-X Solar FTU-V Solar, FTU-X Solar FTW-V Solar, FTW-X Solar

(AT) BEDIENTUNGSANLEITUNG

(CH) BEDIENTUNGSANLEITUNG

(CZ) NÁVOD K POUŽÍVÁNÍ

(DE) BEDIENTUNGSANLEITUNG

(DK) MONTERINGSVEJLEDNING

(ES) MANUAL DEL USUARIO

(FR) MANUEL D'UTILISATION

(FI) KÄYTTÄJÄN OHJEET

(GB) USER MANUAL

(GR) ΕΓΧΕΙΡΙΔΙΟ ΧΡΗΣΤΗ

(HR) UPUTE ZA KORIŠTENJE

(HU) HASZNÁLATI ÚTMUTATÓ

(IT) ISTRUZIONI D'USO

(LV) LIETOŠANAS INSTRUKCIJA

(LT) STOGO LANGO EKSPLOATACIJOS INSTRUKCIJA

(NO) BRUKSANVISNING FOR FAKRO TAKVINDU

(NL) GEBRUIKSAANWIJZING

(PL) INSTRUKCJA UŻYTKOWANIA

(RO) INSTRUCȚIUNI DE UTILIZARE



(RU) ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ

(SE) BRUKSANVISNING

(SK) NÁVOD K OBSLUHE

(SI) NAVODILA ZA UPORABO

(UA) ІНСТРУКЦІЯ ПО ЕКСПЛУАТАЦІЇ



FTP-V Solar
FTP-X Solar
FTU-V Solar
FTU-X Solar
FTW-X Solar
FTW-V Solar



1234567890

Z-Wave Solar

FTP-X P50 APSX 78x118

87G406 4222 01

FAKRO

www.fakro.com

CE

ARF/254

78x118 (78/118)

Art. Nr ARF AAAA25406






5 900988 920619









ARS
ARP
ARF
AJP
APS
APF




AMZ
ARZ
























FTP-V Solar
FTU-V Solar
FTW-V Solar













FTP-X Solar
FTU-X Solar
FTW-X Solar


















DC 2.5/5.5



14.4V

